



**PC ADAPTORS**

**PS/2 KEYBOARD ADAPTOR**

Connects a Keyboard AT to PS/2, Molded, PVC Beige  
DIN 5 Female to MDIN 6 Male  
**KP0506FM-02** 6"



DIN 5 Male to MDIN 6 Female  
**KP0506MF-01** 6"



**MODULAR ADAPTOR**

Use modular adaptors to run client server applications. Connect terminals on the desktop back to a central patch panel or directly to a MUX via RS232, many network planners have implemented modular adapters as the most cost effective way to complete the connections. For terminals, serial printers, modems, POS and other serial equipment.

**AD2545-M** DB25M-RJ45  
**AD2545-F** DB25F-RJ45



**AD0945-M** DB9M-RJ45  
**AD0945-F** DB9F-RJ45



**AD0912-M** DB9M-RJ12  
**AD0912-F** DB9F-RJ12



**AD2512-M** DB25M-RJ12  
**AD2512-F** DB25F-RJ12



**AD1545-M** DB15M-RJ45  
**AD1545-F** DB15F-RJ45



**Y.C. Cable**  
**The Only Connection**  
**You Need !**

**MOUSE ADAPTOR**

**AD0609FF**  
PS/2 TO AT MOUSE, MD6 Female-DB9 Female, 6"  
**AD0609MM**  
AT MOUSE TO PS/2, DB9 Male-MD6 Male, 6"



**MOUSE Y ADAPTOR**

Y-Mouse adaptors give you the power to connect two devices to the same port. With these small, easy to use Y shaped adaptors you don't have to open your computer or install any drivers.

**ADT-0606-Y** MD6M-MD6Fx2 1'  
**ADT-0606-Y-KM** MD6M-MD6Fx2 1' keyboard/mouse

